

Keeping your Digital Signage Displays and Professional TVs clean and free of dust and fingerprints is essential for the best viewing experience. Now, more than ever before, keeping them free of bacteria and viruses is a critical part of your health and safety practices.

What you'll need

- Two lint-free or microfibre cloths please do not use abrasive cloths such as paper towels as these will scratch your display.
- For touchscreens: 1.5% hydrogen peroxide solution.
- For non-touchscreens: Mild soap (or non-alcoholic cleaning fluid) solution.

NB. When using soap, please select a product that does not leave a 'grease' residue as this may collect bacteria, viruses and dust.

Preparing to clean

- Turn off the display and disconnect the power supply.
- Disconnect any peripheral devices, including USB drives, dongles and media players.
- Wipe the display with a dry lint-free or microfibre cloth to remove loose dirt and dust.

Your cleaning regimen

- Moisten a clean cloth so that it is just damp, rather than soaking, using 1.5% hydrogen peroxide for touchscreens or non-alcoholic, non-ammoniac, mild cleaning fluid for non-touchscreens.
- Never spray cleaning fluid directly onto the display, as this may cause damage to internal components. Always use a cloth to apply the fluid.
- Gently wipe the cloth across the screen, remembering to wipe in one direction only.
- Allow to air dry thoroughly before powering up your display.

For your safety

- 1 Wear disposable gloves when cleaning your displays, helping you to avoid contact with germs and any chemicals.
- 2 Always replace and fully close cleaning fluid container lids and ensure they are stored safely after use.
- **3** Wash your hands thoroughly after cleaning your display, even if you were wearing gloves.

www.philips.com/pds